

NEXINEO

**NEXINEO ICT CLASSROOM UNPACKING
INSTRUCTIONS**

PACKAGE CONTENTS

The complete NEXINEO classroom kit includes the following components:


- NEXI GO server
- NEO virtual desktop devices
- MikroTik router
- Switch TP-Link



All of these components will arrive to you carefully packed in one box placed on a pallet. Cut the binding strips and remove the corner profiles.




Carefully cut the adhesive tape that covers the box, open the box and remove the protective PE foam.



Remove the filling material – bubble wrap. Take out the NEO virtual desktop devices, switch(es) and the router.



Carefully pull the NEXI GO Server box out of the large box using the tie wraps. **The NEXI GO Server box must always be pulled out by two persons at a time! The weight of the NEXI GO server is approximately 25 kilograms!** Place the server box horizontally (in the direction of the label).




Carefully cut the adhesive tape on the NEXI GO server box, undo the box flaps, flip the box upright and pull it upwards.



After removing the box, remove the power cord taped to the back of the NEXI GO server.



Remove the protective polystyrene and plastic bag from the NEXI GO server.



REMOVAL OF FILLING MATERIALS

Pull the side panel of the NEXI GO server with the warning sticker off by pulling on the marked handle.



Remove the filling material (bubble wrap) from inside the NEXI GO server.



Put the side panel back on.



After the unpacking of the NEXINEO system, you can complete the physical installation of the NEXINEO system according to the NEXINEO INSTALLATION AND OPERATING MANUAL found on the website shop.nexineo.com under the "Support" section.

CONTACT INFORMATION

support@nexineo.com

shop.nexineo.com

www.nexineo.com